

Fire & Ice Beaded Earrings

Create stunning Swarovski® earrings in a few simple steps.
The color options are endless!

steps:

1. Using the **Swanstrom super-flush cutters**, cut three 2½" lengths of the **red Beadalon® wire**.
2. Pass all three wires through one **sterling crimp bead**. Pass all three wires back through the crimp bead, creating a small loop of wires above the crimp bead about halfway along the wires. Pull the wires through to varying lengths for interesting asymmetry.
3. Add a **Swarovski® bead** to one of the wires; slide a **sterling 2mm crimp** onto the wire and squeeze it closed with the **Swanstrom flat-nose pliers**. Snip off any excess wire with the super-flush cutters.
4. Repeat step 3 for the remaining wires.
5. Using the **Swanstrom chain-nose pliers**, twist open the loop on the **sterling French ear wire** and attach the Beadalon dangle to the earring. Close the loop securely.
6. Pinch a **sterling crimp cover** around the top crimp. Use the **bead-crimping pliers** to gently squeeze the crimp cover completely closed.
7. Bend the wires so they fan out slightly from the crimp cover.
8. Repeat for the second earring.



supplies:

Description	Order #	Qty.
Swarovski® faceted round bead, 4mm, Crystal AB	075-787/13	4
Swarovski® faceted tapered bead, 6mm, Siam	075-792/49	8
Sterling French ear wire with loop	630-004	2
Sterling crimp bead	693-230	12
Sterling crimp, 2mm	630-150	2
Sterling crimp cover	694-930	2
Beadalon® 7 six-color assortment	681-849	15" of red
Bead-crimping pliers	111-616	1
Swanstrom flat-nose pliers	111-301	1
Swanstrom super-flush cutters	111-713	1
Swanstrom chain-nose pliers with Delrin® jaws	111-204	1



800.545.6566 riogrande.com